



UBR Ultra Clear Epoxy Mixing Instructions

Handle Paste

Rear Handle + Butt Cap

2ml Part A + 1ml Part B + 1 level teaspoon Fumed Silica

Reel Seat + Front Grip

4ml Part A + 2ml Part B + 1 heaped teaspoon Fumed Silica

Instructions:

1. Add 2 parts of A with 1 part of B to a mixing cup.
2. Add fumed silica powder to the mix.
3. Stir thoroughly for 5 minutes with a stirring stick.
4. Working time is approximately 30mins at 25°C
5. Check the mix. If it is stiff enough to stick to the stirring stick without dripping it is good. If it is a bit runny add a small amount of fumed silica until it is the right consistency.

Finishing Epoxy – enough for all guide wraps and ferrule wrap

2ml Part A + 1ml Part B

Instructions:

1. In your mixing cup add 2 parts of A with 1 part of B to a **clean** mixing cup.
2. Stir thoroughly for 5 minutes using a mixing stick. Scrape the edges of the mixing container to ensure complete and thorough mixing has been achieved. Keep your movements slow and the stirrer touching the bottom of the mixing cup. Stirring too quickly can introduce unwanted bubbles into the mix.